

SAFETY TURTLETM SOS SENSORS

READ THESE INSTRUCTIONS IN ADDITION TO THE SAFETY TURTLE USER GUIDE

1. **Warning:** SOS sensors are NOT intended for use on young children.
2. **Warning:** Reliable alarming depends on unobstructed fill holes. See fig. 1. Periodically check and clear the four fill holes.
3. **Warning:** When used in sea water, SOS sensors should be worn on the upper torso so as to immerse then break the surface of the water. See fig. 3a.
4. **Warning:** SOS wristbands do not float.
5. SOS wristbands can be attached around wrist or more tightly to a life vest or rescue tube strap. See fig. 2 & fig. 3a and 3b.
6. SOS sensors are factory installed on visors. See fig. 4.
7. When completely immersed, the cavity of the SOS sensor immediately fills with water as illustrated in fig. 5. Alarming will occur when the cavity is about ½ full.
8. Water must be drained from the SOS sensor as illustrated in fig. 5. The sensor will cease transmitting in a few seconds.
9. There is no need to towel dry the SOS sensor.
10. **Warning:** Do not attempt to separate the plastic shells of the SOS sensors. If alarming does not stop immediately, ensure the holes are clear, shake gently and let air dry.

Figure 1




Figure 2



Figure 3a



Figure 3b



Figure 4



Figure 5

